



Portable Spectrophotometer PS-2200



\$4,610.00

Portable Spectrophotometer	Portable Spectrophotometer PS-2000 series	Spectrophotometer
----------------------------	---	-------------------

Portable Spectrophotometer PS-2200 portable spectrophotometer used/8° geometry of sphere measurement diffused illumination integrating systems illuminate an object equally from all directions or angles and detects the reflected light at 8°. Suitable for color matching for many industries and widely used in the painting industry, textile industry, plastic industry, food industry, building material industry, and other industries for color quality control. A flexible LED light source that has balanced intensity across the visible spectrum avoids the spectral deficiency in certain parts of the spectrum in common white LEDs, and guarantees the speed of the measurement and the accuracy of the results. It used to measure specular component excluded (SCE) or specular component included (SCI) mode and used ETC Technology (Every Test Calibration).

[Add To Cart](#)

Product Description

Portable Spectrophotometer PS-2200 portable spectrophotometer used/8° geometry of sphere measurement diffused illumination integrating systems illuminate an object equally from all directions or angles and detects the reflected light at 8°. Suitable for color matching for many industries and widely used in the painting industry, textile industry, plastic industry, food industry, building material industry, and other industries for color quality control. A flexible LED light source that has balanced intensity across the visible spectrum avoids the spectral deficiency in certain parts of the spectrum in common white LEDs, and guarantees the speed of the measurement and the accuracy of the results. It used to measure specular component excluded (SCE) or specular component included (SCI) mode and used ETC Technology (Every Test Calibration).

Similar Products



Buy Now



Buy Now



Buy Now



Buy Now